




More on Serial Communication

Serial Communication between Arduino and PC (via USB)

- Serial communication can be established by connecting the Arduino to your PC.




- You'll need to select the correct Arduino type and the Port in the IDE
- Eg. The one shown is a MEGA 2560 and COM3 (this port is automatically set by PC)




Serial Communication between Arduino and PC (via USB)

- To receive / send data at PC side, you'll need to open the Serial Monitor (work as a terminal)




Serial Monitor


- **Menu 1:** Determine how to end the sending string; whether special character NL(newline) or CR (Carriage return) are appended at the end or not.
- **Menu 2:** Set the baud rate (data transfer speed)



Menu 1



Menu 2



- Serial is a class (containing many functions)

<https://www.arduino.cc/reference/en/language/functions/communication/serial/>

- Serial.begin(val)
 - One parameter
 - val: baud rate, eg. 9600, 57600 ...
 - It is used to set the baud rate for the serial communications. Need to match with the one set in Serial Monitor

```
//----- SETUP SERIAL PORT -----  
Serial.begin(9600);  
while(!Serial)  
    ;           //Leonardo/Micro should wait for serial init
```

- **Serial** is true if the port is ready.
- Serial.end (): Disable serial communication

Some functions for Sending to Serial Monitor (Arduino→PC)

- Sending text or string of texts

```
Serial.print("Hello");           //Write string no new line  
Serial.println(my_variable);     //Write a value with line break at end
```

- Sending Variable as ASCII

`Serial.print(78, BIN)` gives "1001110"

`Serial.print(78, OCT)` gives "116"

`Serial.print(78, DEC)` gives "78"

`Serial.print(78, HEX)` gives "4E"

`Serial.println(1.23456, 0)` gives "1"



`Serial.println(1.23456, 2)` gives "1.23"

`Serial.println(1.23456, 4)` gives "1.2346"

Default is two decimals.

Receiving from Serial Monitor (PC → Arduino)

- Basic Concept about a communication channel



- (i) At Arduino side, the texts are stored in a receive buffer

- (i) ASCII codes are sent, which are interpreted as text characters
- (ii) Menu 1 specifies how you end the sending texts.

Example:



If **Newline** is chosen in Menu 1, and “abc” is sent. At the receive buffer, there will be 4 characters, “abc” plus “the new line character”.

If **No line ending** is chosen in Menu 1, and “abc” is sent. At the receive buffer, there will be 3 characters, “abc”

Some functions

- [Serial.available\(\)](#)
 - Get the number of bytes (characters) arrived and stored in the serial receive buffer (which holds 64 bytes).
- [Serial.parseInt\(\)](#)
 - Get the first valid integer number from serial buffer.
 - Parsing stops when no characters have been read for a configurable time-out value, or a non-digit is read;
 - If no valid digits were read when the time-out (see `Serial.setTimeout()`) occurs, 0 is returned;
- [Serial.readString\(\)](#)
 - Read characters from serial buffer and output the string (a string of characters)

Examples



```
while (Serial.available() > 0)
{
    str1 = Serial.readString();
}
```

- (1) Str1 becomes a string of 4 characters: "abc" + NL
- (2) Str1 becomes a string of 5 characters: "abc" + NL + CR
- (3) Strange characters

```
while (Serial.available() > 0)
{
    a = Serial.parseInt();
}
```

- (4) a = 123 and then a=0
- (5) a = 123

- (1) If **Newline** is chosen in Menu 1, and send "abc"
- (2) If **both NL & CR** is chosen in Menu 1, and send "abc"
- (3) baud rate does not match with the program
- (4) If **Newline** is chosen in Menu 1, and send "123"
- (5) **No line ending** is chosen in Menu 1, and send "123"

Note: There are also other commands available.